



CONTROL PARTS - Top Boards

| PART # | MODEL # | DESCRIPTION |
|------------------|---------------|-----------------------------|
| E53-4956 | CIP-1 | TOP BOARD & HOUSING |
| E53-4973 | CM3-2 | TOP BOARD & HOUSING |
| E53-4943 | CM10-2 | TOP BOARD & HOUSING |
| E53-4811 | CPS-1 | TOP BOARD & HOUSING |
| E53-4861 | CPS-2M | TOP BOARD & HOUSING |
| E53-8312C | CPS-2C | TOP BOARD ONLY |
| E53-8813 | CPS-3M | TOP BOARD & HOUSING |
| E53-8653 | DIP-1 | TOP BOARD & HOUSING |
| E53-8312C | DIP-1C | TOP BOARD ONLY |
| E53-8113 | ECS-1M | TOP BOARD & HOUSING |
| E53-8213 | ECS-2M | TOP BOARD & HOUSING |
| E53-8313 | ECS-3M | TOP BOARD & HOUSING |
| E53-8312C | ECS-3C | TOP BOARD ONLY |
| E53-8413 | ECS-4M | TOP BOARD & HOUSING |
| E53-8513 | ECS-5M | TOP BOARD & HOUSING |
| E53-8312C | ECS-5C | TOP BOARD ONLY |
| E53-4313 | EMC-2 | TOP BOARD & HOUSING |
| E53-9701 | GE-64X | GE (1,2,4,6) TOP BOARD ONLY |
| E53-9801 | GE-32 | TOP BOARD ONLY |
| E53-5143 | IC-47 | TOP BOARD & HOUSING |
| E53-5133 | IC-410ND | TOP BOARD & HOUSING |
| E53-5112 | IC-610/LX | TOP BOARD ONLY |
| E53-9003 | LX-641 | TOP BOARD & HOUSING |
| E53-9013 | LX-642 | TOP BOARD & HOUSING |
| E53-9023 | LX-644 | TOP BOARD & HOUSING |
| E53-9103 | LX-646 | TOP BOARD & HOUSING |
| E53-9321 | MC-22 | TOP BOARD & HOUSING |
| E53-3613 | MST-1 | TOP BOARD & HOUSING |
| E53-3653 | MST-1H1 | TOP BOARD & HOUSING |
| E53-3643 | MST-2B | TOP BOARD & HOUSING |
| E53-8853 | MST-5 | TOP BOARD & HOUSING |
| E53-8312C | MST-5C | TOP BOARD ONLY |
| E53-4451 | MVS-1 | TOP BOARD & HOUSING |
| E53-4452C | MVS-1C | TOP BOARD ONLY |
| E53-4461 | MVS-2 | TOP BOARD & HOUSING |
| E53-4991 | RCM-40 | TOP BOARD & HOUSING |
| E53-3413 | SA-10 | TOP BOARD & HOUSING |
| E53-3412C | SA-10C | TOP BOARD ONLY |
| E53-5273 | SVIM-1 | TOP BOARD & HOUSING |
| E53-8902 | THO-2 | TOP BOARD & HOUSING |
| E53-4333 | TLC-4200 | TOP BOARD & HOUSING |
| E53-4961 | VSM-2 | TOP BOARD & HOUSING |

If you would like a quote to repair a control, the control needs to be returned to our vendor for evaluation. Allow 3-4 weeks for repair pricing.

NOTE: It is advisable NOT TO REPAIR controls that are 5 years old or older.

CONTROL PARTS - Bottom Boards

| PART # | MODEL # | DESCRIPTION |
|----------|--------------|-------------------------------------|
| E53-4957 | CIP-1 | BOTTOM BOARD & HOUSING |
| E53-4974 | CM3-2 | BOTTOM BOARD & HOUSING |
| E53-4821 | CPS-1 | BOTTOM BOARD & HOUSING |
| E53-4881 | CPS-2M | BOTTOM BOARD & HOUSING |
| E53-8823 | CPS-3M | BOTTOM BOARD & HOUSING |
| E53-8654 | DIP-1 | BOTTOM BOARD & HOUSING |
| E53-8652 | X1060/DIP-1 | DIP-1 BOTTOM BOARD ONLY |
| E53-8123 | ECS-1M | BOTTOM BOARD & HOUSING |
| E53-8223 | ECS-2M | BOTTOM BOARD & HOUSING |
| E53-8323 | ECS-3M | BOTTOM BOARD & HOUSING |
| E53-8423 | ECS-4M | BOTTOM BOARD & HOUSING |
| E53-8523 | ECS-5M | BOTTOM BOARD & HOUSING |
| E53-4323 | EMC-2 | BOTTOM BOARD & HOUSING |
| E53-9802 | X1159/GE-32 | BOTTOM BOARD ONLY |
| E53-5144 | IC-47 | BOTTOM BOARD & HOUSING |
| E53-5135 | X1096/IC-410 | BOTTOM BOARD ONLY |
| E53-5115 | X1059/IC-610 | BOTTOM BOARD ONLY |
| E53-9004 | LX-641 | BOTTOM BOARD & HOUSING |
| E53-9002 | X1059/LX-641 | BOTTOM BOARD ONLY |
| E53-9014 | LX-642 | BOTTOM BOARD & HOUSING |
| E53-9012 | X1059/LX-642 | BOTTOM BOARD ONLY |
| E53-9024 | LX-644 | BOTTOM BOARD & HOUSING |
| E53-9022 | X1059/LX-644 | BOTTOM BOARD ONLY |
| E53-9323 | MC-22 | BOTTOM BOARD & HOUSING |
| E53-9325 | X1127/MC-22 | BOTTOM BOARD ONLY |
| E53-3623 | MST-1/MST-2 | BOTTOM BOARD & HOUSING |
| E53-4523 | MST-3 | BOTTOM BOARD ONLY |
| E53-8854 | MST-5 | BOTTOM BOARD & HOUSING |
| E53-4992 | RCM-40 | BOTTOM BOARD & HOUSING |
| E53-3423 | SA-10 | BOTTOM BOARD & HOUSING |
| E53-5275 | X1104/SVIM-1 | BOTTOM BOARD ONLY (24 VOLT) |
| E53-5265 | X1088/SVIM-1 | BOTTOM BOARD ONLY (120 VOLT) |
| E53-4334 | TLC-4200 | BOTTOM BOARD & HOUSING |
| E53-8904 | THO-2 | BOTTOM BOARD & HOUSING |
| E53-9042 | X1188/VPM-2 | BOTTOM BOARD ONLY |
| E53-4962 | VSM-2 | BOTTOM BOARD & HOUSING |
| E53-4959 | X188/VSM-2 | BOTTOM BOARD ONLY |
| E53-8680 | DIP-1 | TRANSFORMER |
| E53-5276 | SVIM | TRANSFORMER |

"C" SERIES BOTTOM BOARDS

MAIN BOARDS DO NOT INCLUDE MICROPROCESSOR BOARD "CORE 50".

| PART # | MODEL # | DESCRIPTION |
|------------------|----------------|-----------------------------|
| E53-8324C | X1300/ECS-3C | MAIN BOARD ONLY |
| E53-8524C | X1300/ECS-5C | MAIN BOARD ONLY |
| E53-8651C | X1340/DIP-1C | MAIN BOARD ONLY |
| E53-8852C | X1336/MST-5C | MAIN BOARD ONLY |
| E53-4851C | X1344/CPS-2C | MAIN BOARD ONLY |
| E53-3422C | X1341/SA-10C | MAIN BOARD ONLY |
| E53-4454C | X1341/MVS-1C | MAIN BOARD ONLY |
| E53-8326C | CORE 50 | MICROPROCESSOR BOARD |